

ENG: **SALAMANDER BLUEVOLUTION 92 DOORS**
(OPENING INWARDS)

Threshold/ Sash 171O4O

FR: **SALAMANDER BLUEVOLUTION 92 PORTE**
(OUVERTURE VERS L'INTÉRIEUR)


Seuil/ L'ouvrant 171O4O

DE: **SALAMANDER BLUEVOLUTION 92 TÜR**
(NACH INNEN ÖFFNEN)

Schwelle/ Flügel 171O4O

IT: **SALAMANDER BLUEVOLUTION 92 PORTA**
(APERTURA VERSO L'INTERNO)

Soglia/ Anta 171O4O



ENG: **SALAMANDER BLUEVOLUTION 92 DOORS**
(OPENING OUTWARDS)

Threshold/ Sash 371O4O

FR: **SALAMANDER BLUEVOLUTION 92 PORTE**
(OUVERTURE VERS L'EXTÉRIEUR)

Seuil/ L'ouvrant 371O4O

DE: **SALAMANDER BLUEVOLUTION 92 TÜR**
(NACH AUSSEN ÖFFNEN)

Schwelle/ Flügel 371O4O

IT: **SALAMANDER BLUEVOLUTION 92 PORTA**
(APERTURA VERSO L'ESTERNO)

Soglia/ Anta 371O4O